

部 品 表

ILLUSTRATED PARTS LIST

FOR

SINGER

MACHINE

1591D 200A
240A
300A
308A

CONTENTS

目


次

COVERS 1 -----	1
カバー 1	
COVERS 2 -----	2
カバー 2	
BOBBIN WINDER AND BOBBIN WINDER TENSION -----	3
ボビンワインダー、ボビンワインダーテンション	
ARM SHAFT -----	4
上軸	
NEEDLE BAR AND TAKE-UP LEVER -----	5
針棒、天ビン	
PRESSER BAR, PRESSER FOOT AND PRESSER BAR LIFTER -----	6
押エ棒、自由押エ、押エ上げ	
FEED MECHANISM 1 -----	7
送り 1	
FEED MECHANISM 2 -----	8
送り 2	
FEED MECHANISM 3 -----	9
送り 3	
UPRIGHT SHAFT AND ROTATING HOOK SHAFT -----	10
堅軸、下軸	
LUBRICATING MECHANISM -----	11
給油、運送	
ACCESSORIES AND ATTACHMENTS -----	12
付属品	
PARTS AVAILABLE AT EXTRA CHARGE -----	13
別売品	

COVERS 1


カバー 1

-1-



NO.	部品番号 PART NO.	0200A	0210A	0300A	数量 QTY.	名称	DESCRIPTION
1	550009	●	●	●	1	ベッド脚(長)	BED LEG (LONG)
2	550010	●	●	●	3	ベッド脚(短)	BED LEG (SHORT)
3	544368	●	●	●	2	アーム, ベッド脚メネジ(前)	ARM SCREW (FRONT)
4	543826	●	●	●	2	アーム, ベッド脚メネジ(前) 通金	ARM SCREW (FRONT) WASHER
5	545033	●	●	●	2	アーム, ベッド脚メネジ(後)	ARM SCREW (BACK)
6	504064	●	●	●	1	アーム, ベッド脚メネジ(小)	ARM SCREW (SMALL)
7	505001	●	●	●	2	アーム, ベッドノックピン	ARM DOWEL PIN
8	550011	●	●	●	1	ベッドホールプラグ	ARM HOLE PLUG
9	550013-451	●	●	●	1	アーム上蓋, パッキン(通)	ARM TOP COVER AND ARM TOP COVER PACKING COMP.
10	550015	●	●	●	1	アーム上蓋パッキン	ARM TOP COVER PACKING
11	545944	●	●	●	1	オイルフローウィンドウ	OIL FLOW WINDOW
12	550020	●	●	●	1	上糸案内	THREAD GUIDE
13	544207-012	●	●	●	1	上糸案内止メネジ	THREAD GUIDE SCREW
14	544213-053	●	●	●	4	アーム上蓋留メネジ	ARM TOP COVER SCREW
15	505317-452	●	●	●	1	スベリ板(通)	BED SLIDE COMP.
16	12431-452	●	●	●	1	スベリ板	BED SLIDE
17	154884	●	●	●	1	スベリ板バネ	BED SLIDE SPRING
18	154789-451	●	●	●	2	スベリ板バネ止メネジ	BED SLIDE SPRING SCREW
19	414464	●	●	●	1	針板(取出)	THROAT PLATE (EXP.)
	541599	●	●	●	1	針板(取内)	THROAT PLATE (DOM.)
	12482-452	●	●	●	1	針板	THROAT PLATE
	376391	●	●	●	1	針板	THROAT PLATE
20	691-845	●	●	●	2	針板止メネジ	THROAT PLATE SCREW
21	550035-451	●	●	●	1	面板, パッキン(通)	FACE PLATE AND FACE PLATE PACKING COMP.
22	550037	●	●	●	1	面板パッキン	FACE PLATE PACKING
23	368041	●	●	●	1	アーム糸通ケ(左)	THREAD EYELET (SIDE OF ARM)
24	544212-001	●	●	●	1	アーム糸通ケ(左) 止メネジ	THREAD EYELET (SIDE OF ARM) SCREW
25	368063	●	●	●	1	面板プラグ(大)	FACE PLATE LARGE PLUG
26	368037	●	●	●	1	面板プラグ(小)	FACE PLATE SMALL PLUG
27	544212-004	●	●	●	3	面板止メネジ	FACE PLATE SCREW
28	544886	●	●	●	1	アームホールプラグ(大)	ARM HOLE PLUG (LARGE)
29	544782	●	●	●	3	アームホールプラグ(小)	ARM HOLE PLUG (SMALL)


COVERS 2
カバー 2



NO.	品 目 番 号 PART NO.	0200A	0210A	0100A	0108A	取 組 順 号	名 称	DESCRIPTION
1	550040-451	●	●	●	●	1	スピンガード	THREAD TAKE-UP LEVER GUARD
2	544212-012	●	●	●	●	2	スピンガード止メネジ	THREAD TAKE-UP LEVER GUARD SCREW
3	368042	●	●	●	●	1	アーム取付ネジ (右)	THREAD GUARD (SIDE OF ARM)
4	544212-001	●	●	●	●	1	アーム取付ネジ (左) 止メネジ	THREAD GUARD (SIDE OF ARM) SCREW
5	52454	●	●	●	●	1	スプリング取付ネジ	THREAD RETAINER
6	544203-001	●	●	●	●	1	スプリング取付ネジ止メネジ	THREAD RETAINER SET SCREW
7	376439-452	●	●	●	●	1	上糸調節ネジ (右)	TENSION COMP.
	376440-452	●	●	●	●	1	上糸調節ネジ (左)	TENSION COMP.
8	32758	●	●	●	●	1	糸取りバネ	THREAD TAKE-UP SPRING
9	540682	●	●	●	●	1	糸取りバネ	TENSION SPRING
	125314	●	●	●	●	1	糸取りバネ	TENSION SPRING
10	368082	●	●	●	●	1	糸取りバネ	THREAD TAKE-UP SPRING REGULATOR
11	504047	●	●	●	●	1	糸取りバネ止メネジ	TENSION STUD SET SCREW
12	540533	●	●	●	●	1	糸取りバネ用パッキン	THREAD TAKE-UP SPRING REGULATOR O-RING
13	540534	●	●	●	●	1	糸取りバネ用キャップ	THREAD TAKE-UP SPRING REGULATOR RUBBER CAP
14	414273	●	●	●	●	1	糸取りバネ用ワッシャー	TENSION RELEASE DISC
15	545898	●	●	●	●	1	糸取りバネ	TENSION STUD
16	413500-452	●	●	●	●	1	糸取りつまみ	TENSION REGULATING THUMB NUT
17	411154	●	●	●	●	1	糸取りつまみ	TENSION REGULATING THUMB NUT WASHER
18	2102	●	●	●	●	2	糸取りつまみ	TENSION DISC
19	540684	●	●	●	●	1	糸取りつまみ	TENSION RELEASE PIN
20	368430	●	●	●	●	1	糸取りバネ止メネジ	THREAD TAKE-UP SPRING REGULATOR SET SCREW
21	550044-451	●	●	●	●	1	ハズミネジ (右)	MACHINE PULLEY COMP.
22	504119	●	●	●	●	2	ハズミネジ止メネジ	MACHINE PULLEY SET SCREW

BOBBIN WINDER AND BOBBIN WINDER TENSION


ボビンワインダー、ボビンワインダーテンション



NO.	品 番 号 PART NO.	0200A	0210A	0300A	0300A	数量 QTY.	名 称	DESCRIPTION
1	550021-451	●	●	●	●	1	ボビンワインダー (組)	BOBBIN WINDER COMP.
2	550022-451	●	●	●	●	1	ボビンワインダー (体)	BOBBIN WINDER
3	550026	●	●	●	●	1	糸巻車	BOBBIN WINDER PULLEY
4	543871-022	●	●	●	●	1	糸巻車オリング	BOBBIN WINDER PULLEY RING (RUBBER)
5	550028	●	●	●	●	1	糸巻器台	BOBBIN WINDER BRACKET
6	546844	●	●	●	●	2	糸巻器スラストワッシャー	BOBBIN WINDER SPINDLE THRUST WASHER
7	282758	●	●	●	●	1	糸巻器スラストカラー (組)	BOBBIN WINDER SPINDLE THRUST COLLAR COMP.
8	544206-011	●	●	●	●	2	糸巻器スラストカラー止メネジ	BOBBIN WINDER SPINDLE THRUST COLLAR SET SCREW
9	411097	●	●	●	●	1	糸巻器バネ	BOBBIN WINDER SPINDLE SPRING
10	544865	●	●	●	●	1	ボビンワインダーバネ	BOBBIN WINDER SPRING
11	368020	●	●	●	●	1	糸巻器台作動板	BOBBIN WINDER BRACKET ACTUATING PLATE
12	550029	●	●	●	●	1	ボビンワインダーストップバー (組)	BOBBIN WINDER STOPPER COMP.
13	544207-013	●	●	●	●	2	ボビンワインダーストップバー止メネジ	BOBBIN WINDER STOPPER SCREW
14	550032	●	●	●	●	1	ボビンワインダーレバー (組)	BOBBIN WINDER STOP LUTCH COMP.
15	544208-005	●	●	●	●	1	ボビンワインダーレバー止メネジ	BOBBIN WINDER STOP LUTCH SET SCREW
16	368025	●	●	●	●	1	ボビンワインダーレバー軸	BOBBIN WINDER STOP LUTCH STUD
17	543860-005	●	●	●	●	1	ボビンワインダーレバー軸止メネジ	BOBBIN WINDER STOP LUTCH STUD SNAP RING
18	546847	●	●	●	●	1	糸巻器バネ	BOBBIN WINDER BRACKET SPRING
19	368026	●	●	●	●	1	糸巻器調節器 (組)	BOBBIN WINDER REGULATOR COMP.
20	544208-005	●	●	●	●	1	糸巻器調節器止メネジ	BOBBIN WINDER REGULATOR SET SCREW
21	368028	●	●	●	●	1	ボビン受	BOBBIN WINDER SPINDLE THREAD GUARD
22	544217-001	●	●	●	●	3	ボビンワインダー止メネジ	BOBBIN WINDER SCREW
23	548061	●	●	●	●	3	ボビンワインダー止メネジ座金	BOBBIN WINDER SCREW WASHER
24	368029	●	●	●	●	1	ボビンワインダーテンション (組)	BOBBIN WINDER TENSION COMP.
25	368030	●	●	●	●	1	ボビンワインダーテンション軸 (組)	BOBBIN WINDER TENSION STUD COMP.
26	547246	●	●	●	●	1	ボビンワインダーテンションバネ	BOBBIN WINDER TENSION SPRING
27	547247	●	●	●	●	2	ボビンワインダーテンション両子通	BOBBIN WINDER TENSION DISC
28	368033	●	●	●	●	1	ボビンワインダーテンションワッシャー	BOBBIN WINDER TENSION REGULATING THUMB NUT
29	544204-001	●	●	●	●	1	ボビンワインダーテンション止メネジ	BOBBIN WINDER TENSION SET SCREW

ARM SHAFT


上軸



NO.	部品番号 PART NO.	0200A	0210A	0300A	0310A	数量 QTY.	名称	DESCRIPTION
1	376353	●	●	●	●	1	上軸, 内合クラック (蓋)	ARM SHAFT (HORIZONTAL) AND NEEDLE BAR CRANK COMP.
2	376352	●	●	●	●	1	上軸 (蓋)	ARM SHAFT (HORIZONTAL)
3	504095	●	●	●	●	1	針棒クラック止メネジ	THREAD TAKE-UP CRANK SET SCREW
4	504117	●	●	●	●	1	針棒クラック両メネジ	THREAD TAKE-UP CRANK SET SCREW
5	374100	●	●	●	●	1	内合クラック止メネジ	NEEDLE BAR CRANK POSITION SCREW
6	540706	●	●	●	●	1	上軸メタル (後)	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (BACK)
7	504002	●	●	●	●	1	上軸メタル (後) 止メネジ	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (BACK) SET SCREW
8	540707	●	●	●	●	1	上軸メタル (後) オイルシール	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (BACK) OIL SEAL
9	550038	●	●	●	●	1	糸巻器蓋 (蓋)	BOBBIN WINDER DRIVING WHEEL COMP.
10	544207-011	●	●	●	●	2	糸巻器蓋止メネジ	BOBBIN WINDER DRIVING WHEEL SET SCREW
11	545762-001	●	●	●	●	1	上軸カラー (蓋)	ARM SHAFT (HORIZONTAL) THRUST COLLAR COMP.
12	504101	●	●	●	●	2	上軸カラー止メネジ	ARM SHAFT (HORIZONTAL) THRUST COLLAR SET SCREW
13	545758	●	●	●	●	1	上軸メタル (中)	ARM SHAFT (HORIZONTAL) BUSHING (CENTER)
14	504002	●	●	●	●	1	上軸メタル (中) 止メネジ	ARM SHAFT (HORIZONTAL) BUSHING (CENTER) SET SCREW
15	540720	●	●	●	●	1	上軸メタル (前) (蓋)	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (FRONT) COMP.
16	540406	●	●	●	●	1	上軸メタル (前)	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (FRONT)
17	540722	●	●	●	●	1	上軸メタル (前) オイルドレンチューブ蓋	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (FRONT) OIL TUBE TAPE
18	504002	●	●	●	●	1	上軸メタル (前) 止メネジ	ARM SHAFT (HORIZONTAL) FLANGED BUSHING (FRONT) SET SCREW
19	540476	●	●	●	●	1	針棒クラック蓋金	THREAD TAKE-UP CRANK WASHER
20	543365	●	●	●	●	1	天ビンオイルウィック支エ (蓋)	OIL WICK HOLDER COMP.
	543366	●	●	●	●	1	天ビンオイルウィック支エ (蓋)	OIL WICK HOLDER COMP.
21	543363	●	●	●	●	1	天ビンオイルウィック支エ, パイプ (蓋)	OIL WICK HOLDER AND PIPE
	543364	●	●	●	●	1	天ビンオイルウィック支エ, パイプ (蓋)	OIL WICK HOLDER AND PIPE
22	545909	●	●	●	●	2	天ビンオイルウィック	OIL WICK (COTTON)
23	545051	●	●	●	●	1	天ビンオイルウィック支エ止メネジ	OIL WICK HOLDER SCREW

NEEDLE BAR AND TAKE-UP LEVER


針棒, 天ビン



NO.	品番 PART NO.	0200A 0210A 0300A	名称 名 称	DESCRIPTION
1	550052	●	天ビン, 針棒クランクロッド (組)	THREAD TAKE-UP COMP.
	550054	●	天ビン, 針棒クランクロッド (組)	THREAD TAKE-UP COMP.
	550248	●	天ビン, 針棒クランクロッド (組)	THREAD TAKE-UP COMP.
2	543369	●	天ビン支え棒 (組)	THREAD TAKE-UP LEVER LINK HINGE STUD COMP.
3	543368	●	天ビン支え棒	THREAD TAKE-UP LEVER LINK HINGE STUD
4	543370	●	天ビン支え棒オイルワック	THREAD TAKE-UP LEVER LINK HINGE STUD OIL WICK (COTTON)
5	543367	●	天ビン支え	THREAD TAKE-UP LEVER LINK
6	540676	●	天ビン (組)	THREAD TAKE-UP LEVER COMP.
	540751	●	天ビン (組)	THREAD TAKE-UP LEVER COMP.
7	52130	●	天ビン油蓋	THREAD TAKE-UP LEVER THREAD EYELET BUSHING
8	543871-002	●	天ビンOリング	THREAD TAKE-UP LEVER O-RING
9	540677	●	針棒クランク	THREAD TAKE-UP CRANK
	540685	●	針棒クランク	THREAD TAKE-UP CRANK
10	504118	●	針棒クランクロッド止メジ	NEEDLE BAR CONNECTING LINK CAP SCREW
11	368069	●	針棒クランクロッド	NEEDLE BAR CONNECTING LINK
12	544881	●	針棒軸ネ (組)	NEEDLE BAR CONNECTING STUD COMP.
13	549380	●	針棒軸ネ締めメジ	NEEDLE BAR CONNECTING STUD CLAMPING SCREW
14	143058	●	針棒軸ネスライドブロック	NEEDLE BAR CONNECTING STUD SLIDE BLOCK
15	540662	●	針棒クランクロッドローラーベアリング	NEEDLE BAR CONNECTING LINK ROLLER BEARING
16	540662	●	天ビンローラーベアリング	THREAD TAKE-UP LEVER ROLLER BEARING
17	504002	●	天ビン支え止メネジ	THREAD TAKE-UP LEVER LINK HINGE STUD SET SCREW
18	376394	●	天ビンオイルガード (組)	THREAD TAKE-UP LEVER OIL GUARD COMP.
19	376396	●	天ビンオイルガードオイルワック	THREAD TAKE-UP LEVER OIL GUARD WICK (COTTON)
20	504063-451	●	天ビンオイルガード止メネジ	THREAD TAKE-UP LEVER OIL GUARD SCREW
21	N19550-114	●	針 (135×65#14) (組出)	NEEDLE (135X65#14) (EXP.)
	N15150-110	●	針 (16X95#10) (組内)	NEEDLE (16X95#10) (DOH.)
	N19550-116	●	針 (135×65#16) (組出)	NEEDLE (135X65#16) (EXP.)
	N15150-114	●	針 (16X95#14) (組内)	NEEDLE (16X95#14) (DOH.)
	N19550-121	●	針 (135×65#21)	NEEDLE (135X65#21)
22	540702	●	針棒 (組) (組出)	NEEDLE BAR (HOLLOW) COMP. (EXP.)
	376231	●	針棒 (組) (組内)	NEEDLE BAR (HOLLOW) COMP. (DOH.)
	540698	●	針棒 (組) (組出)	NEEDLE BAR (HOLLOW) COMP. (EXP.)
	376229	●	針棒 (組) (組内)	NEEDLE BAR (HOLLOW) COMP. (DOH.)
	543409	●	針棒 (組)	NEEDLE BAR (HOLLOW) COMP.
23	504112	●	針止メネジ	NEEDLE SET SCREW
24	375571	●	針棒糸巻ネ (組出)	NEEDLE BAR THREAD GUARD (EXP.)
	372321	●	針棒糸巻ネ (組内)	NEEDLE BAR THREAD GUARD (DOH.)
25	545841	●	針棒メタル (上)	NEEDLE BAR BUSHING (UPPER)
26	504129	●	針棒メタル (上) 止メネジ	NEEDLE BAR BUSHING (UPPER) SET SCREW
27	540703	●	針棒メタル (上) フェルト	NEEDLE BAR BUSHING (UPPER) FELT
28	540524	●	針棒メタル (下)	NEEDLE BAR BUSHING (LOWER)
	540525	●	針棒メタル (下)	NEEDLE BAR BUSHING (LOWER)
29	368446	●	針棒メタル (下) 糸巻ネ	NEEDLE BAR BUSHING (LOWER) THREAD EYELET
	368495	●	針棒メタル (下) 糸巻ネ	NEEDLE BAR BUSHING (LOWER) THREAD EYELET
30	504129	●	針棒メタル (下) 止メネジ	NEEDLE BAR BUSHING (LOWER) SET SCREW
31	540528	●	針棒メタル (下) フェルト	NEEDLE BAR BUSHING (LOWER) FELT

PRESSER BAR, PRESSER FOOT AND PRESSER BAR LIFTER

押工棒, 自由押工, 押工上げ




NO.	品番 PART NO.	0200A 0240A 0300A 0304A	数量 QTY.	名称	DESCRIPTION
1	545864	●	1	押工棒	PRESSER BAR (HOLLOW)
2	505643	●	1	自由押工 (通) (引出)	PRESSER FOOT (SPRING HINGED) COMP. (EXP.)
	543059	●	1	自由押工 (通) (留内)	PRESSER FOOT (SPRING HINGED) COMP. (IDOM.)
	543419	●	1	自由押工 (通)	PRESSER FOOT (SPRING HINGED) COMP.
	541585-002	●	1	自由押工 (通)	PRESSER FOOT (SPRING HINGED) COMP.
3	504063-451	●	1	自由押工止めネジ	PRESSER FOOT SCREW
4	505649	●	1	押工棒メタル	PRESSER BAR BUSHING (LOWER)
5	504129	●	1	押工棒メタル止めネジ	PRESSER BAR BUSHING (LOWER) SET SCREW
6	376423	●	1	押工調整ネジ	PRESSURE REGULATING SCREW
7	376424	●	1	押工調整ネジナット	PRESSURE REGULATING SCREW NUT
8	414342	●	1	押工調整ネジ案内溝	PRESSURE REGULATING SCREW GUIDE ROD
9	414341	●	1	押工棒バネ	PRESSER BAR SPRING
10	550056	●	1	押工棒ガイドキ (通)	PRESSER BAR GUIDE BRACKET COMP.
11	504095	●	1	押工棒ガイドキ止めネジ	PRESSER BAR GUIDE BRACKET SCREW
12	505575	●	1	押工棒バネ	PRESSER BAR SPRING
13	111170	●	1	押工棒バネ固定金	PRESSER BAR SPRING WASHER
14	544425	●	1	押工調整ネジ	PRESSURE REGULATING THUMB SCREW
15	544424	●	1	押工調整ネジ	LOW PRESSURE ADJUSTING SCREW
16	410941	●	1	押工取付用バネ	PRESSER FOOT SPRING (COMPRESSION)
17	410988	●	1	押工棒 (通)	PRESSER BAR (HOLLOW)
18	410944	●	1	押工棒リテーナ	PRESSER FOOT RETAINER
19	549013	●	1	押工棒リテーナ止めネジ	PRESSER FOOT RETAINER SCREW
20	410942	●	1	押工棒カラー (通)	PRESSER BAR COLLAR COMP.
21	544207-011	●	2	押工棒カラー止めネジ	PRESSER BAR COLLAR SCREW
22	545403	●	1	押工調整ネジロックナット	PRESSURE REGULATING THUMB SCREW LOCK NUT
23	550075	●	1	糸調子板	SLACK THREAD REGULATOR COMP.
24	544212-001	●	2	糸調子板止めネジ	SLACK THREAD REGULATOR SCREW
25	550058-451	●	1	押工上げ	PRESSER BAR LIFTER
26	544212-055	●	1	押工上げ止めネジ	PRESSER BAR LIFTER SET SCREW
27	543804-003	●	1	押工上げ止めネジ固定金	PRESSER BAR LIFTER SET SCREW WASHER
28	550059	●	1	押工上げカム (通)	PRESSER BAR LIFTER CAM COMP.
29	543871-003	●	1	押工上げカムOリング	PRESSER BAR LIFTER CAM SHAFT O-RING
30	550069	●	1	鐘上げ連結棒	BELL CRANK CONNECTING ARM
31	550070	●	1	鐘上げ連結棒 (押し)	BELL CRANK CONNECTING ROD (PUSH)
32	550071	●	1	鐘上げ連結棒戻りシバネ	BELL CRANK CONNECTING ARM SPRING
33	550072	●	1	鐘上げ連結棒戻りネジ	BELL CRANK CONNECTING ARM HINGE SCREW
34	543871-008	●	1	鐘上げ連結棒戻りネジOリング	BELL CRANK CONNECTING ARM HINGE SCREW O-RING
35	543801-006	●	2	鐘上げ連結棒戻り止めネジ	BELL CRANK CONNECTING ARM HINGE SCREW SNAP RING
36	368089	●	1	鐘上げ連結棒 (引き) 戻りネジ (裏)	BELL CRANK CONNECTING ROD (PULL) STUD SCREW (BACK)
37	550063	●	1	押工上げ爪	PRESSER BAR LIFTER ARM
38	550064	●	1	鐘上げ連結棒 (引き)	BELL CRANK CONNECTING ROD (PULL)
39	368089	●	1	鐘上げ連結棒 (引き) 戻りネジ (表)	BELL CRANK CONNECTING ROD (PULL) STUD SCREW (FRONT)
40	550065	●	1	押工上げ案内板	PRESSER BAR LIFTER ARM GUIDE BRACKET
41	550067	●	1	押工上げ調整ネジ	PRESSER BAR LIFTER HINGE SCREW
42	543871-008	●	1	押工上げ調整ネジOリング	PRESSER BAR LIFTER HINGE SCREW O-RING
43	543801-006	●	1	押工上げ調整ネジ止めネジ	PRESSER BAR LIFTER HINGE SCREW SNAP RING
44	550066	●	1	糸調子作動ピン	TENSION RELEASE ACTUATING PIN

FEED MECHANISM 1

送り 1


-7-



NO.	部品番号 PART NO.	0200A	0210A	0300A	0301A	数量 QTY.	名 称	DESCRIPTION
1	544933	●	●	●	●	1	上下送り軸	FEED LIFTING ROCK SHAFT
2	545807	●	●	●	●	1	上下送り軸(後) (組)	FEED LIFTING ROCK SHAFT CRANK (BACK) COMP.
3	549183	●	●	●	●	2	上下送り軸(後) 留メネジ	FEED LIFTING ROCK SHAFT CRANK (BACK) CLAMPING SCREW
4	545806	●	●	●	●	2	上下送り軸カラー (組)	FEED LIFTING ROCK SHAFT COLLAR COMP.
5	504007	●	●	●	●	4	上下送り軸カラー止メネジ	FEED LIFTING ROCK SHAFT COLLAR SET SCREW
6	545949	●	●	●	●	2	上下送り軸メタル	FEED LIFTING ROCK SHAFT FLANGED BUSHING
7	545812	●	●	●	●	1	上下送り軸クロッド (組)	FEED LIFTING ROCK SHAFT CRANK (BACK) CONNECTING ROD COMP.
8	543488	●	●	●	●	1	上下送り軸クロッド (組)	FEED LIFTING ROCK SHAFT CRANK (BACK) CONNECTING ROD COMP.
9	545059	●	●	●	●	2	上下送り軸クロッド 留メネジ	FEED LIFTING ROCK SHAFT CRANK (BACK) CONNECTING ROD CAP SCREW
10	545799	●	●	●	●	1	上下送り軸クロッド ヒンジスタッド	FEED LIFTING ROCK SHAFT CRANK (BACK) CONNECTING ROD HINGE STUD
11	365450	●	●	●	●	1	水平送り軸	FEED ROCK SHAFT
12	414290	●	●	●	●	1	水平送り軸	FEED ROCK SHAFT
13	545836	●	●	●	●	1	水平送り軸メタル (前)	FEED ROCK SHAFT FLANGED BUSHING (FRONT)
14	504094	●	●	●	●	1	水平送り軸メタル (前) 止メネジ	FEED ROCK SHAFT FLANGED BUSHING (FRONT) SET SCREW
15	410806	●	●	●	●	1	水平送り軸メタル (中)	FEED ROCK SHAFT BUSHING (INTERMEDIATE)
16	545949	●	●	●	●	1	水平送り軸メタル (後)	FEED ROCK SHAFT FLANGED BUSHING (BACK)
17	543871-012	●	●	●	●	1	水平送り軸 O-RING	FEED ROCK SHAFT O-RING
18	545837	●	●	●	●	1	水平送り軸カラー (組)	FEED ROCK SHAFT COLLAR COMP.
19	504007	●	●	●	●	2	水平送り軸カラー止メネジ	FEED ROCK SHAFT COLLAR SET SCREW
20	376445	●	●	●	●	1	送り (輸出)	FEED DOG (EXP.)
21	543372	●	●	●	●	1	送り (案内)	FEED DOG (CON.)
22	12481	●	●	●	●	1	送り	FEED DOG
23	143174	●	●	●	●	1	送り	FEED DOG
24	504051	●	●	●	●	2	送り 留メネジ	FEED DOG SCREW
25	376334	●	●	●	●	1	送り 合 (組)	FEED BAR COMP.
26	376384	●	●	●	●	1	送り 合 (組)	FEED BAR COMP.
27	376335	●	●	●	●	1	送り 合 キャリア (組)	FEED BAR CARRIER COMP.
28	544207-013	●	●	●	●	2	送り 合 ヒンジピン 留メネジ	FEED BAR HINGE PIN CLAMPING SCREW
29	549028	●	●	●	●	1	送り 合 キャリア 留メネジ	FEED BAR CARRIER CLAMPING SCREW
30	545987	●	●	●	●	1	送り 合	FEED BAR
31	543482	●	●	●	●	1	送り 合	FEED BAR
32	545791	●	●	●	●	1	送り 合 ヒンジピン	FEED BAR HINGE PIN
33	540538	●	●	●	●	1	送り 合 キャリア オイル Wick フェルト	FEED BAR CARRIER OIL WICK (FELT)
34	376268	●	●	●	●	1	上下送り軸 リンク	FEED BAR CONNECTING LINK
35	504103	●	●	●	●	2	上下送り軸 リンク 止メネジ	FEED BAR CONNECTING LINK CAP SCREW
36	545808	●	●	●	●	1	上下送り軸 (前) (組)	FEED LIFTING ROCK SHAFT CRANK (FRONT) COMP.
37	545043	●	●	●	●	1	上下送り軸 (前) 留メネジ	FEED LIFTING ROCK SHAFT CRANK (FRONT) CLAMPING SCREW
38	543871-012	●	●	●	●	1	上下送り軸 O-RING	FEED LIFTING ROCK SHAFT O-RING

FEED MECHANISM 2

送り 2




NO.	部品番号 PART NO.	D200A	D210A	D300A	D306A	数量 QTY.	名称	DESCRIPTION
1	376434	●	●	●	●	1	送りカム (組)	FEED AND FEED LIFTING ECCENTRIC COMP.
2	545313	●	●	●	●	2	送りカム止めネジ	FEED AND FEED LIFTING ECCENTRIC SET SCREW
3	543866-022	●	●	●	●	1	送りカムリング	FEED AND FEED LIFTING ECCENTRIC RING
4	550249	●	●	●	●	1	水平送りカム (組)	FEED ECCENTRIC COMP.
5	545313	●	●	●	●	2	水平送りカム止めネジ	FEED ECCENTRIC SET SCREW
6	543472	●	●	●	●	1	上下送りカム (組)	FEED LIFTING ECCENTRIC COMP.
7	504048	●	●	●	●	2	上下送りカム止めネジ	FEED LIFTING ECCENTRIC SET SCREW
8	550101	●	●	●	●	1	送り調節ボルト (組)	FEED REGULATOR HINGE STUD COMP.
9	543871-010	●	●	●	●	1	送り調節ボルトリング	FEED REGULATOR HINGE STUD O-RING
10	545313	●	●	●	●	1	送り調節ボルト止めネジ	FEED REGULATOR HINGE STUD SET SCREW
11	368120	●	●	●	●	1	送り調節ボルトカラー (組)	FEED REGULATOR HINGE STUD COLLAR COMP.
12	545181	●	●	●	●	1	送り調節ボルトカラー止めネジ	FEED REGULATOR HINGE STUD COLLAR SET SCREW
13	550103	●	●	●	●	1	送り調節ボルト (組)	FEED REGULATING STUD COMP.
14	543871-007	●	●	●	●	1	送り調節ボルトリング	FEED REGULATING STUD O-RING
15	550108-451	●	●	●	●	1	送り調節ダイヤル	FEED REGULATING DIAL
	550109-451	●	●	●	●	1	送り調節ダイヤル	FEED REGULATING DIAL
	550257-383	●	●	●	●	1	送り調節ダイヤル	FEED REGULATING DIAL
16	544218-053	●	●	●	●	1	送り調節ダイヤル止めネジ	FEED REGULATING DIAL CAP SCREW
17	543803-004	●	●	●	●	1	送り調節ダイヤル止めネジ座金	FEED REGULATING DIAL CAP SCREW WASHER
18	545820	●	●	●	●	1	送り調節ダイヤルロックピンバネ	FEED REGULATING DIAL LOCK PIN SPRING
19	368114	●	●	●	●	1	送り調節ダイヤルロックピン	FEED REGULATING DIAL LOCK PIN
20	550110-451	●	●	●	●	1	送り逆イレバー (組)	FEED REVERSE LEVER ASS'Y
21	550112	●	●	●	●	1	送り逆イレバー (組)	FEED REVERSE LEVER COMP.
22	550115-451	●	●	●	●	1	送り逆イレバーカバー	FEED REVERSE LEVER COVER
23	544212-053	●	●	●	●	2	送り逆イレバーカバー止めネジ	FEED REVERSE LEVER COVER SET SCREW
24	543871-006	●	●	●	●	1	送り逆イレバー軸リング	FEED REVERSE LEVER HINGE STUD O-RING
25	368129	●	●	●	●	1	送り逆イレバー軸メタル	FEED REVERSE LEVER HINGE STUD FLANGED BUSHING
26	540633	●	●	●	●	1	送り逆イレバー軸カラー (組)	FEED REVERSE LEVER HINGE STUD COLLAR COMP.
27	504134	●	●	●	●	1	送り逆イレバー軸カラー止めネジ	FEED REVERSE LEVER HINGE STUD COLLAR SET SCREW
28	368130	●	●	●	●	1	送り逆イレバーバネ	FEED REVERSE LEVER SPRING
29	540800	●	●	●	●	1	送り逆イレバー制限	FEED REVERSE LEVER STOPPER
30	549164-002	●	●	●	●	1	送り逆イレバー制限止めネジ	FEED REVERSE LEVER STOPPER SCREW

FEED MECHANISM 3

送り 3


-9-



NO.	品番 PART NO.	数量 QTY.	名称	DESCRIPTION
1	550089	1	水平送りクランクロッド、送り調節器、送り調節器、送り調節レバー(大)	FEED REGULATOR AND FEED SHAFT CRANK CONNECTING ROD COMP.
2	540648	1	水平送りクランクロッド、送り調節器、送り調節器、送り調節レバー(大)	FEED REGULATOR AND FEED SHAFT CRANK CONNECTING ROD COMP.
3	545059	1	水平送りクランクロッド(大)	FEED ROCK SHAFT CRANK CONNECTING ROD COMP.
4	545181	1	水平送りクランクロッド(大)	FEED ROCK SHAFT CRANK CONNECTING ROD COMP.
5	540649	1	水平送りクランクロッド(大)	FEED ROCK SHAFT CRANK CONNECTING ROD COMP.
6	540655	1	水平送りクランクロッド(大)	FEED ROCK SHAFT CRANK CONNECTING ROD COMP.
7	540656	1	水平送りクランクロッド(大)	FEED ROCK SHAFT CRANK CONNECTING ROD COMP.
8	376239	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
9	540644	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
10	543404	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
11	549183	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
12	545181	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
13	540650	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
14	550092	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
15	550252	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
16	544138	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
17	376240	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
18	550094	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
19	368103	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
20	368105	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
21	550095	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
22	550255	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
23	550096	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
24	550097	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
25	544204-002	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
26	543801-006	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
27	550098	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
28	549288	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
29	368111	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
30	414737	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
31	540653	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
32	410746	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
33	504029	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
	550256	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
	550100	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW
	544213-054	1	送り調節器リンク止メネジ	FEED ROCK SHAFT CRANK CONNECTING ROD CAP SCREW

UPRIGHT SHAFT AND ROTATING HOOK SHAFT

堅軸, 下軸




NO.	部品番号 PART NO.	0200A 0210A 0300A 0304A	数量 QTY.	名称	DESCRIPTION
1	545757	●	1	上軸歯車(組)	ARM SHAFT (HORIZONTAL) BEVEL GEAR COMP.
2	504066	●	2	上軸歯車止メネジ	ARM SHAFT (HORIZONTAL) BEVEL GEAR SET SCREW
3	545767	●	1	堅軸メタル(上)	ARM SHAFT (UPRIGHT) BUSHING (UPPER)
4	545766	●	1	堅軸メタル(下)	ARM SHAFT (UPRIGHT) BUSHING (LOWER)
5	545765	●	1	堅軸歯車(上)(組)	ARM SHAFT (UPRIGHT) BEVEL GEAR (UPPER) COMP.
6	504101	●	2	堅軸歯車(上)止メネジ	ARM SHAFT (UPRIGHT) BEVEL GEAR (UPPER) SET SCREW
7	550118	●	1	堅軸	ARM SHAFT (UPRIGHT)
8	545764	●	1	堅軸歯車(下)(組)	ARM SHAFT (UPRIGHT) BEVEL GEAR (LOWER) COMP.
9	504101	●	2	堅軸歯車(下)止メネジ	ARM SHAFT (UPRIGHT) BEVEL GEAR (LOWER) SET SCREW
10	414126	●	1	外ガマ, 中ガマ(組)	ROTATING HOOK AND ROTATING HOOK BOBBIN CASE HOLDER COMP.
	543381	●	1	外ガマ, 中ガマ(組)	ROTATING HOOK AND ROTATING HOOK BOBBIN CASE HOLDER COMP.
11	544244	●	2	外ガマ止メネジ	ROTATING HOOK SCREW
12	544745	●	1	ネピンケース(組)	ROTATING HOOK BOBBIN CASE COMP.
13	55623	●	1	ネピン	ROTATING HOOK BOBBIN
14	545881	●	1	中ガマ止メ	ROTATING HOOK BOBBIN CASE HOLDER POSITION BRACKET
15	504084	●	1	中ガマ止メネジ	ROTATING HOOK BOBBIN CASE HOLDER POSITION BRACKET SCREW
16	550119	●	1	下軸(組)	ROTATING HOOK SHAFT COMP.
17	550120	●	1	下軸	ROTATING HOOK SHAFT
18	505648	●	1	下軸オイルフィルター(組)	ROTATING HOOK SHAFT OIL FILTER COMP.
19	143042	●	1	下軸オイルフィルターウェック	ROTATING HOOK SHAFT OIL FILTER WICK (FELT)
20	505647	●	1	下軸軸止メネジ	ROTATING HOOK SHAFT OIL FILTER WICK HOLDER
21	368386	●	1	下軸カラー(組)	ROTATING HOOK SHAFT OIL RETAINING COLLAR COMP.
22	504101	●	2	下軸カラー止メネジ	ROTATING HOOK SHAFT OIL RETAINING COLLAR SET SCREW
23	550121	●	1	下軸メタル(前)	ROTATING HOOK SHAFT BUSHING (FRONT)
24	504002	●	1	下軸メタル(前)止メネジ	ROTATING HOOK SHAFT BUSHING (FRONT) SET SCREW
25	544246	●	1	流量調節ネジ	ROTATING HOOK OIL FLOW REGULATING THUMB SCREW
26	544958	●	1	流量調節ネジスプリング	ROTATING HOOK OIL FLOW REGULATING THUMB SCREW SPRING
27	545887	●	1	下軸歯車(組)	ROTATING HOOK SHAFT BEVEL GEAR (LEFT HAND SPIRAL)
28	504101	●	2	下軸歯車止メネジ	ROTATING HOOK SHAFT BEVEL GEAR SET SCREW
29	550122	●	1	下軸メタル(後)	ROTATING HOOK SHAFT BUSHING (BACK)
30	504002	●	1	下軸メタル(後)止メネジ	ROTATING HOOK SHAFT BUSHING (BACK) SET SCREW
31	550123	●	1	下軸オイルシール	ROTATING HOOK SHAFT OIL SEAL

LUBRICATING MECHANISM

給油, 還流


-11-



NO.	部品番号 PART NO.	0200A	0210A	0300A	0310A	数量 QTY.	名称	DESCRIPTION
1	550124	●	●	●	●	1	オイルポンプ (組)	OIL PUMP (CENTRIFUGAL) COMP.
2	544968	●	●	●	●	1	オイルポンプ (体)	OIL PUMP (CENTRIFUGAL)
3	544969	●	●	●	●	1	インペラー	OIL PUMP (CENTRIFUGAL) IMPELLER
4	544970	●	●	●	●	1	オイルポンプ蓋	OIL PUMP (CENTRIFUGAL) COVER
5	544248	●	●	●	●	4	オイルポンプ蓋止めネジ	OIL PUMP (CENTRIFUGAL) COVER SCREW
6	544971	●	●	●	●	1	オイルポンプスクリーン	OIL PUMP (CENTRIFUGAL) SCREEN
7	544972	●	●	●	●	1	還流ピストン	OIL REMOVING PISTON
8	410710	●	●	●	●	1	還流ピストンバネ	OIL REMOVING PISTON SPRING
9	414716	●	●	●	●	1	還流ピストンバネ押エネジ (組)	OIL REMOVING PISTON SPRING SCREW COMP.
10	550125	●	●	●	●	1	オイルポンプブラケット	OIL PUMP (CENTRIFUGAL) BRACKET
11	544211-004	●	●	●	●	3	オイルポンプブラケット止めネジ	OIL PUMP (CENTRIFUGAL) BRACKET SCREW
12	543814-001	●	●	●	●	3	オイルポンプブラケット止めネジ蓋金	OIL PUMP (CENTRIFUGAL) BRACKET SCREW WASHER
13	541164-001	●	●	●	●	3	オイルポンプブラケット止めネジナット	OIL PUMP (CENTRIFUGAL) BRACKET SCREW NUT
14	544213-001	●	●	●	●	2	オイルポンプ (組) 止めネジ	OIL PUMP (CENTRIFUGAL) SCREW
15	368137	●	●	●	●	1	還流チューブ (組)	OIL REMOVING TUBE COMP.
16	16380	●	●	●	●	1	還流チューブスクリーン	OIL REMOVING LINT SCREEN
17	543371	●	●	●	●	1	還流チューブ穴工	OIL REMOVING TUBE RETAINING CLAMP
18	544212-001	●	●	●	●	1	還流チューブ穴工止めネジ	OIL REMOVING TUBE RETAINING CLAMP SCREW
19	543334	●	●	●	●	1	還流チューブ止めバネ	OIL TUBE CLAMP
20	550128	●	●	●	●	1	オイルパイプ (上側用)	OIL TUBE (ARM SHAFT)
21	544964	●	●	●	●	1	オイルパイプ (上側用) 継手	OIL TUBE (ARM SHAFT) JOINT
22	414085	●	●	●	●	1	オイルチューブ (下側用) (組)	OIL TUBE (ROTATING HOOK SHAFT) COMP.
23	410773	●	●	●	●	1	オイルチューブ (下側用)	OIL TUBE (ROTATING HOOK SHAFT)
24	543332	●	●	●	●	1	オイルチューブ (下側用) 継手	OIL TUBE (ROTATING HOOK SHAFT) JOINT

ACCESSORIES AND ATTACHMENTS


付属品



NO.	部品番号 PART NO.	0200A	0210A	0300A	0302A	数量 QTY.	名称	DESCRIPTION
1	550157	●	●	●	●	1	油受け(蓋)	MACHINE BASE AND OIL RESERVOIR COMP.
2	550158	●	●	●	●	1	油受け	MACHINE BASE AND OIL RESERVOIR
3	544978	●	●	●	●	1	油受けガスケット	MACHINE BASE AND OIL RESERVOIR GASKET
4	545036	●	●	●	●	1	油受けドレーンネジ	MACHINE BASE AND OIL RESERVOIR OIL DRAIN PLUG SCREW
5	545754	●	●	●	●	1	油受けドレーンネジパッキン	MACHINE BASE AND OIL RESERVOIR OIL DRAIN PLUG SCREW GASKET
6	368377	●	●	●	●	4	マシン油受けクッション	MACHINE REST (RUBBER)
7	368267	●	●	●	●	1	岩当座	ROCK SHAFT
8	545915	●	●	●	●	1	岩当座(蓋)	ROCK SHAFT CRANK COMP.
9	545922	●	●	●	●	1	岩当座止メ(蓋)	ROCK SHAFT STOP DOG COMP.
10	545921	●	●	●	●	1	岩当座バネ	ROCK SHAFT SPRING
11	543823-001	●	●	●	●	2	スラストワッシャー	THRUST WASHER
12	550159	●	●	●	●	1	原上ゲプランジャー	BELL CRANK PLUNGER COMP.
13	544895	●	●	●	●	1	岩当座	ROCK SHAFT KNEE ARM
14	376436	●	●	●	●	1	岩当座実エ(蓋)	ROCK SHAFT KNEE ARM HUB COMP.
15	414115	●	●	●	●	1	岩当座(蓋)	ROCK SHAFT KNEE ARM PLATE COMP.
16	541515	●	●	●	●	1	クロスガイド	CLOTH GUIDE
17	504030	●	●	●	●	1	クロスガイド止メネジ	CLOTH GUIDE SCREW
18	55623	●	●	●	●	3	ボビン	ROTATING HOOK BOBBIN
19	368317	●	●	●	●	1	ドライバー(大)	SCREW DRIVER (LARGE)
20	541514	●	●	●	●	1	ドライバー(小)	SCREW DRIVER (SMALL)
21	548701	●	●	●	●	1	ドライバー(長)	SCREW DRIVER (LONG)
22	545754	●	●	●	●	1	油受けドレーンネジパッキン	MACHINE BASE AND OIL RESERVOIR OIL DRAIN PLUG SCREW GASKET
23	410154	●	●	●	●	1	油カン(C型オイル750cc)	OIL CAN (750cc. FILLED WITH SINGER TYPE "C" OIL)
24	410186	●	●	●	●	1	レストピン	MACHINE REST PIN
25	540520	●	●	●	●	2	油受けクッション(大)(前ラム)(露出)	MACHINE BASE AND OIL RESERVOIR CUSHION (FRONT) (EXP.)
26	368379	●	●	●	●	2	油受けクッション(大)(前ラム)(露出)	MACHINE BASE AND OIL RESERVOIR CUSHION (FRONT) (DOM.)
27	540521	●	●	●	●	2	油受けクッション(小)(前ラム)(露出)	MACHINE BASE AND OIL RESERVOIR CUSHION (BACK) (EXP.)
28	368380	●	●	●	●	2	油受けクッション(小)(前ラム)(露出)	MACHINE BASE AND OIL RESERVOIR CUSHION (BACK) (DOM.)
29	540522	●	●	●	●	2	マシンヒンジ	MACHINE HINGE CONNECTION
30	540523	●	●	●	●	2	マシンヒンジ受け(露出)	MACHINE HINGE CONNECTION CUSHION (EXP.)
31	368381	●	●	●	●	2	マシンヒンジ受け(露出)	MACHINE HINGE CONNECTION CUSHION (DOM.)
32	546920	●	●	●	●	2	マシンヒンジ受け(露出)	MACHINE HINGE CONNECTION CUSHION WIRE NAIL
33	505656-007	●	●	●	●	1	2本糸交合(蓋)	THREAD UNWINDER (FOR TWO SPOOLS) COMP.
34	414301	●	●	●	●	1	付属品袋	ACCESSORY PACK
35	414407	●	●	●	●	1	マシンカバー(露出)	MACHINE COVER
36	376430	●	●	●	●	1	針パック(N1955-01#14,3本入)(露出)	NEEDLE PACK (N1955-01#14) (EXP.)
37	376431	●	●	●	●	1	針パック(N1955-01#16,3本入)(露出)	NEEDLE PACK (N1955-01#16) (EXP.)
38	N15150-110	●	●	●	●	3	針(16X95#10)(露出)	NEEDLE (16X95#10) (DOM.)
39	N15150-114	●	●	●	●	3	針(16X95#14)(露出)	NEEDLE (16X95#14) (DOM.)
40	N19550-121	●	●	●	●	3	針(135X65#16)(露出)	NEEDLE (135X65#16) (EXP.)

PARTS AVAILABLE AT EXTRA CHARGE

別売品



NO.	部品番号 PART NO.	0200A	0210A	0300A	0300A	数量 QTY.	名称	DESCRIPTION
1	550162-451	●	●	●	●	1	ベルトガード(上)	BELT GUARD COMP.
2	550163-451	●	●	●	●	1	ベルトガード(左)	BELT GUARD (LEFT)
3	550164-451	●	●	●	●	1	ベルトガード(右)	BELT GUARD (RIGHT)
4	544213-058	●	●	●	●	3	ベルトガード止メネジ	BELT GUARD SCREW
5	544212-007	●	●	●	●	3	ベルトガード止メネジ	BELT GUARD SCREW
6	541165-001	●	●	●	●	3	ベルトガード止メネジナット	BELT GUARD SCREW NUT
7	550165-451	●	●	●	●	1	ベルトガード(下)(上)	BELT GUARD (LOWER) COMP.
8	550166-451	●	●	●	●	1	ベルトガード(下)	BELT GUARD (LOWER)
9	550167-451	●	●	●	●	1	ベルトガードスライド	BELT GUARD SLIDE
10	550168	●	●	●	●	1	ベルトガードスライドプレート	BELT GUARD SLIDE PLATE
11	544211-053	●	●	●	●	2	ベルトガードスライド止メネジ	BELT GUARD SLIDE SCREW
12	550169	●	●	●	●	1	ベルトガードスライドシャフト	BELT GUARD SLIDE SHAFT
13	368279	●	●	●	●	1	ベルトガードスライドバネ	BELT GUARD SLIDE SPRING
14	408913	●	●	●	●	2	ベルトガードスライドシャフト止メネジ	BELT GUARD SLIDE SHAFT SNAP RING
15	549398	●	●	●	●	4	ベルトガード(下)ボネジ	BELT GUARD (LOWER) WOOD SCREW
16	545945	●	●	●	●	1	ボックスレンチ	BOX WRENCH
17	52032-452	●	●	●	●	1	喉板	THROAT PLATE
	142060-452	●	●	●	●	1	喉板	THROAT PLATE
	142061-452	●	●	●	●	1	喉板	THROAT PLATE
18	149057	●	●	●	●	1	送り	FEED DOG
19	376461	●	●	●	●	1	ニードルガード	NEEDLE GUARD
20	414155	●	●	●	●	1	シール剤	SEAL COMPOUND

Part No.378889-102 (195)
Printed in Japan